

PRODUCT DESCRIPTION

TyKote[®] is a revolutionary way to prepare commercial, residential, and sports wood floors for recoating. All dust, mess, and equipment associated with screening are eliminated when using TyKote. Applied in a liquid state, TyKote acts as an intermediate bonding layer between the existing floor and the new topcoat.

TYPICAL PROPERTIES

Color.....	Translucent (dries clear)
VOC	Does not exceed 125 grams/liter,
Flash Point.....	Greater than 200°F
Freeze/Thaw Stability.....	Stable (if frozen, thaw completely before using)
Drying Time	One hour (with good ventilation)
Clean Up.....	Water
Storage	Do not store above 120°F (49C)

RECOMMENDED APPLICATORS

- Basic Microfiber Mop – easy to use clean residential application tool
- Rayon string mop – fast tool for applying TyKote in sports floors or large rooms

COVERAGE

2,500- 4,000 sqft per gallon, depending on conditions

RECOMMENDED SYSTEMS

1 thin coat of TyKote + 1-2 coats of StreetShoe or Hydroline Plus

PACKAGING

- 1 US gallon plastic jug (4 per case)

APPLICATION PROCEDURES

Note - Do not use over any paste wax surfaces. If unsure, always prepare a test patch to determine potential adhesion. TyKote is recommended for recoat applications only.

1. To prepare the floor for the cleaning process, remove all caked mud, chewing gum, and other debris from the floor. Vacuum the dirt from the floor. Pay special attention to corners.

2. Clean floor with *Basic's Intensive Floor Treatment (IFT)* according to label instructions. Multiple cleanings may be necessary. Be sure floor is entirely free of dirt, oil, and other residue. Depending on the condition of the floor, it may be necessary to repeat this step more than once.
3. Clean the floor again with *Basic's Squeaky Cleaner* according to label instructions. Squeaky Cleaner does not leave a residue.
4. Allow floor to dry completely before applying TyKote. Box fans may be used to speed up the drying process.
5. Rinse clean sponge mop in clean water. Wring out until damp.
6. Shake TyKote gently before use. Apply a small amount of TyKote to an area of the floor and use sponge mop to spread it in a thin, uniform layer. For large floors, pour TyKote into a clean, dry mop bucket. Soak a new, lint-free rayon mop in TyKote and wring out. Work around the floor until all areas have been coated. Be sure that every area of the floor intended for recoat is coated with TyKote. Any missed spots may result in poor adhesion to topcoat. The floor should have a wet appearance but there should be no puddles.
7. Allow to dry approximately one hour with good ventilation and air movement across the floor. If there are areas where the TyKote has not dried, wipe the area with a clean, water-dampened rag. Do not exceed six hours before applying the topcoat or TyKote may lose effectiveness. If the six-hour window is surpassed, tack the floor with *Squeaky Cleaner* to remove any airborne dust before applying TyKote.
8. Apply the Basic water-based topcoat of your choice according to label instructions.

Refer to “Basic’s TyKote[®] Dustless Recoating System” brochure for complete application instructions prior to using the system.

OBLIGATION OF MANUFACTURER/SELLER

The following is made in lieu of all warranties, expressed or implied: Seller’s and manufacturer’s only obligation shall be to replace such quantity of the product proved to be defective. Neither seller nor manufacturer shall be liable for any injury, loss of damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, the user shall determine the suitability of the product for the intended use and user assumes all risk and liability whatsoever in connection therewith. The foregoing may not be altered except by an agreement signed by officers of seller and manufacturer.