



STEP 1

**Step 1:**


Make sure the subfloor is structurally sound, level and is free of dust and debris. Check for protruding nails and/or defects in the subfloor. If installing over concrete, the concrete must be dry with moisture emission rates that do not exceed 3lbs. per 1000 square feet per 24 hours as measured by the Anhydrous Calcium Chloride Test.



STEP 2

**Step 2:**


Start in a corner and begin installing the FloorMuffler parallel to the wall in the opposite direction as you plan to install the flooring planks. When installing the FloorMuffler, leave at least 2" going up the wall.



STEP 3

**Step 3:**

Roll out the next roll of FloorMuffler in the same manner making sure that the foam seams are butted together.



STEP 4

**Step 4:**

If installing the FloorMuffler on concrete or below grade subfloors, be sure to tape the seams together with 2" tape that meets the moisture vapor transmission rate for this type of installation.



STEP 5

**Step 5:**

Install the flooring per manufacturer's instructions.

---

*For more information about FloorMuffler® contact us at 800-440-6008 or visit us at [www.floormuffler.com](http://www.floormuffler.com).*

---